


AIR/ Istruzioni di montaggio / Fitting instructions



codice	A	D	H	I	L
F3...1815	125	1760	1820	1760	303
F3...2015	125	1960	2020	1960	303
F5...1815	325	1760	1820	1760	503
F5...2015	325	1960	2020	1960	503
F7...1815	525	1760	1820	1760	703
F7...2015	525	1960	2020	1960	703